

Index

A

- Adapter, dial-in A-5
- Alarm Call Options 3-27
- Applications
 - advanced 1-5
 - basic 1-4
- AUX 0,1
 - dial-in management..... 2-13

C

- Cables..... A-3, A-4, A-5, A-7, A-8
- Clients, SNMP 3-31
- Configuration Menu 3-17
- Connections
 - AUX 0, AUX 1..... 2-13
 - dial-in management..... 2-11
 - rear panel..... 2-5
 - terminal 2-7
- Console interface 2-6, 2-7, A-1
- Customer support 4-1

D

- Defaults Restart..... 3-21
- Device Selection Menu 3-7
- Diagnostics Menu 3-10
- Dial-in management..... 2-11
 - hot keys 3-8
 - options..... 3-23
- Digital Loop 3-13

E

- Equipment return and repair 4-1

F

- Functional description..... 1-2

H

- Hardware, part numbers.....B-1
- Hot keys 3-8

I

- Installation
 - dial-in management..... 2-10
 - SNMP..... 2-8
 - telnet..... 2-8

- terminal 2-7
- Installation checklist 2-2
- Interfaces
 - console 2-6
 - modem 2-6
 - NI 2-4
 - SNMP..... 2-4
 - V.35 2-6
- IP address, configure..... 3-29

K

- Keys and conventions..... 3-3

L

- Label, multipurpose D-1
- LEDs 2-3
- Line Status 3-14
- Local Loop..... 3-11
- Local Loop + Selftest..... 3-12

M

- Main Menu..... 3-9
- Management Menu 3-29
- MIB 2-10
- Modem
 - dial-in management..... 2-11, 3-23
 - interface 2-6, A-2

N

- Network interface (NI)..... 2-4, A-2

O

- Order numbersB-1

P

- Part numbersB-1
- Password
 - configure 3-20
 - dial-in 3-24
- Password screen 3-6
- Phone numbers, service 4-1
- Power connection 2-4

R

- Remote Digital Loop 3-13

Index

Remote Digital Loop with Selftest 3-14
Return policy 4-1

S

Saving changes 3-3
Screens
 alarm call options 3-27
 configuration 3-17
 device selection 3-7
 diagnostics 3-10
 dial-in management options 3-23
 edit fields 3-3
 header, edit 3-19
 keys and conventions 3-3
 main menu 3-9
 management 3-29
 password 3-6
 saving changes 3-3
 service information 3-22
 system restarts 3-21
 terminal selection 3-5
 trap client table 3-33
 unit 3-19
Selftest 3-11
Service Information 3-22
SLIP
 installation 2-8
 interface 2-4
SNMP interface A-2
SNMP Trap Client Table 3-33
SNMP, telnet 2-8
Specifications C-1
Speed, NI & DTE 3-16
Statistics 3-14

T

Telco loopback tests 3-14
Telnet
 connection 2-8
Terminal
 installation 2-7
Terminal Selection screen 3-5
Timing 3-16
Traps, enterprise 3-31

U

Unit Menu 3-19

V

V.35 interface 2-6, A-3